## Power Optimiser For Australia Module Add-On

P320 / P370 / P404 / P485 / P500 / P505



## **POWEROPTIMISER**

## PV power optimisation at the module-level

- Specifically designed to work with SolarEdge inverters
- Up to 25% more energy
- Superior efficiency (99.5%)
- Mitigates all types of modules mismatchloss, from manufacturing tolerance to partial shading

- Flexible system design for maximum space utilization
- Fast installation with a single bolt
- Next generation maintenance with module level monitoring
- Module-level voltage shutdown for installer and firefighter safety



## / Power Optimiser For Australia Module Add-On

P320 / P370 / P404 / P485 / P500 / P505

Optimiser Model (Typical Module Compatibilty)	P320 <sup>(1)</sup> (for 60-cell modules)	P370 (for high- power 60 and 72-cell modules)	P404 (for 60-cell and 72-cell, short strings)	P485 (for high- voltage modules)	P500 (for 96-cell modules)	P505 (for higher current modules)				
INPUT										
Rated Input DC Power <sup>(2)</sup>	320	370(2)	405(2)	485	500(2)	505 <sup>(2)</sup>	W			
Absolute Maximum Input Voltage (Voc at lowest temperature)	48	60	80	125	80	83	Vdc			
MPPT Operating Range	8 - 48	8 - 60	12.5 - 80	12.5 - 105	8 - 80	12.5-83	Vdc			
Maximum Short Circuit Current (Isc)	11 10.1 14									
Maximum Efficiency	99.5									
Weighted Efficiency	98.8									
Overvoltage Category										
OUTPUT DURING OPERA	TION (POWER	OPTIMISER CON	NNECTED TO OF	PERATING SOLA	REDGE INVERT	TER)				
Maximum Output Current	15									
Maximum Output Voltage		60	85		60	85	Vdc			
OUTPUT DURING STANDB	Y (POWER OPTI	MISER DISCONN	NECTED FROM S	OLAREDGEINVE	RTERORSOLAF	REDGEINVERTE	ROFF)			
Safety Output Voltage per Power Optimiser	1 ± 0.1									
STANDARD COMPLIANCE										
EMC		FCC Part15 Class B, IEC61000-6-2, IEC61000-6-3								
Safety	IEC62109-1 (class II safety), UL1741									
RoHS	Yes									
Fire Safety	VDE-AR-E 2100-712:2013-05									
INSTALLATION SPECIFICA	ATIONS									
Maximum Allowed System Voltage	1000									
Dimensions (W x L x H)	129 x 1	53 x 27.5	129 x 153 x 42.5	129 x 159 x 49.5	129 x 153 x 33.5	129 x 162 x 59	mm			
Weight (including cables)	630	655	775	845	750	1064	gr			
Input Connector	MC4 <sup>(3)</sup>			Single or Dual MC4 <sup>(5)</sup>	MC	_4 <sup>(4)</sup>				
Input Wire Length	0.16									
Output Connector	MC4									
Output Wire Length	0.95 1.2									
Operating Temperature Range	-40 - +85									
Protection Rating	IP68 / NEMA6P									
Relative Humidity	0 - 100									

P320 replaced the P300; They can be used interchangeably and can be connected in the same string
Rated power of the module at STC will not exceed the optimiser "Rated Input DC Power". Modules with up to +5% power tolerance are allowed.
When connecting modules with rated STC power > 350Wp, labels with optimiser de-energising instructions may need to be attached to the optimisers.
For details refer to: http://www.solaredge.com/sites/default/files/se\_optimizer\_deenergizing\_guide\_aus.pdf
For other connector types please contact SolarEdge.
Dual version for parallel connection of 2 thin film modules; P/N: P485-5RMDMRM. In a case of odd number of PV modules in one string it is allowed to install one P485 dual version power optimiser connected to one PV module. When connecting a single module seal the unused input connectors with the supplied pair of seals.

PV System Design Using a Solaredge Inverter <sup>(6)</sup>		Single Phase HD-WAVE	Single Phase	Three Phase Residential <sup>(7)</sup>	Three Phase Commercial	
Minimum String Length (Power Optimisers)	P320, P370, P500	8		8 per array	16	
	P404, P485, P505	6		7 per array	14	
Maximum String Length (Power Optimisers)		25		25 per array	50	
Maximum Power per String		5700 (6000 with SE8000H, SE10000H)	5250	5700	11250	W
Parallel Strings of Different Lengths or Orientations		Yes				
Notes			=	Connect 2 arrays	=	

<sup>(6)</sup> It is not allowed to mix P404/P485/P505 with P320/P370/P500/P650/P730/P850/P800p in one string. With the three phase residential inverters, use either P404/P485/P505 optimisers or



P320/P350/P500 optimisers on an inverter.

Optimisers must be connected in two separate arrays. For complete design guidelines for the three phase residential inverters. refer to: https://www.solaredge.com/sites/default/files/se\_inverter\_installation\_guide\_e\_series\_design\_installation\_addendum\_aus.pdf